



WATER TRUCK WITH AIR GAP



FILL PIPE DETAIL WITH AIR GAP




WATER WAGON WITH AIR GAP



KEYED NOTES:

- 1 FILL PIPE. PERMANENTLY MOUNTED ON TANK. SEE FILL PIPE DETAIL.
- 2 AIR GAP. AIR GAP IS TWICE THE DIAMETER OF FILL PIPE ABOVE FLOOD RIM.
- 3 HOSE CONNECTION.
- 4 FLOOD RIM.
- 5 FIRE HYDRANT METER.
- 6 APPROVED RPBA.
- 7 SUPPORTS REQUIRED.


RPBA = REDUCED PRESSURE BACKFLOW ASSEMBLY



ELEVATED TANK WITH RPBA'S



TANK TRUCKS WITH RPBA'S



REVISIONS	CITY OF ALBUQUERQUE
	WATER
	APPROVED METHODS OF FILLING TANKS
	DWG. 2395 JANUARY 2003